

Carefully attach arm's to the back of the TV

Mount the wall bracket securely.

Then, place the monitor/arms onto the wall bracket.

Finally, slide the long bar under the arms (as pictured) until secure.

Padlock can be attached for additional security.